


# Connect A Camcorder Diagram

You can set up a camera near the head-end, and broadcast live video into your classrooms using the Channel One DRH and cable distribution system.



Connect camcorder to video input as shown. If stereo microphone is built in, connect audio inputs as well (white-to-white; red-to-red).

If microphone is separate, connect to audio inputs as shown (white-to-white; red-to-red).

To view the signal from your camcorder, press the EXT SOURCE button located on the front of the DRH.